

TELEFUNKEN

The best moments of your life!

START GUIDE EASY CALL - DPF T850

I. USE

A . ELECTRICAL CONNECTION

- Connect the end of the main adaptor to the socket provided.
- Connect the main adaptor to a main socket.

B . INSERT CARD

- Insert your memory card or your USB stick into the slot provided.


C . START UP

- Set the switch to the "ON" position.
- The slideshow starts automatically...


CLEANING

Caution! Be sure that your DIGICADRE is turned off before you clean it. Never use a spray or cleaning liquid directly on the frame or the plastic case. To clean your DIGICADRE, wipe the screen with the cloth supplied to remove any dust or other particles. If the screen is still not clean, apply window cleaning product (without ammoniac or alcohol) applied to a soft and clean cloth. To clean the plastic case: Use a dry and clean cloth.


II. Content in box



III. Description of frame




IV. Description of Handset



Please, charge your telephone during 24 hours before the first use.

V. Numeric keys in remote control mode



Step 1 - To put your phone in remote control mode, press the remote control mode key

Step 2 - The message "remote control mode of DPF" appears on the phone display.

Step 3 - To go through the menu, use the phone keys.